

DPR180/DPR250

PCMCIA OPTION

MANUAL




TABLE OF CONTENTS

1. OVERVIEW	1
1.1 WARNING	1
1.2 MAIN FUNCTIONS	2
2. INSTALLATION	3
2.1 INSTALLING THE PCMCIA OPTION BOARD	3
3. OPERATION	13
3.1 OVERVIEW.....	13
3.1.1 PCMCIA card standard compatibility.....	13
3.1.2 PCMCIA card handling	13
3.1.3 Archives summary	14
3.1.4 DOS compatibility	14
3.2 SETUP.....	14
3.2.1 PCMCIA communication interface configuration.....	14
3.2.2 PCMCIA card initialization	15
3.2.3 PCMCIA card test	15
3.2.4 Charts selection	15
3.3 ARCHIVE MANAGEMENT	16
3.3.1 Continuous archiving	16
3.3.2 Event driven archiving	16
3.4 KEYBOARD ARCHIVE MANAGEMENT	16
3.4.1 START/STOP actions.....	16
3.4.2 RESET PCMCIA files	16
3.4.3 REMOVE PCMCIA function.....	17
3.5 PCMCIA INFORMATION	17
3.5.1 PCMCIA status	17
3.5.2 PCMCIA card status display	18
3.5.3 PCMCIA event	18
3.6 PCMCIA FILE DESCRIPTIONS	18
3.6.1 File name conventions.....	18
3.6.2 Import data to the TrendManager software	19
 4. PCMCIA CONFIGURATION.....	 23
4.1 PCMCIA SUB-MATRIX PARAMETERS	23
4.1.1 PCMCIA sub-matrix parameters list	23
4.1.2 Explanation of the classification	23
4.1.3 PCMCIA sub-matrix parameters description	23
4.2 PCMCIA SUB-MATRIX SERVICES	25
4.2.1 PCMCIA sub-matrix services list	25
4.2.2 PCMCIA sub-matrix services description	26

TABLE OF CONTENTS, Continued

5. KITS LIST	29
6. TROUBLESHOOTING	31
6.1 PCMCIA OPTION IS NOT RECOGNIZED BY THE RECORDER (PCMCIA MATRIX DOES NOT APPEAR)	31
6.2 PCMCIA INIT SERVICE IS NOT POSSIBLE	31
6.3 "PCMCIA FULL" MESSAGE IS DISPLAYED ON THE RECORDER	31
6.4 "PCMCIA NOT INIT" MESSAGE IS DISPLAYED ON THE RECORDER.....	31
6.5 "PCMCIA BAD" MESSAGE IS DISPLAYED ON THE RECORDER	31
6.6 "PCMCIA PENDING" MESSAGE IS DISPLAYED ON THE RECORDER	32
6.7 PCMCIA TRIANGLE DOES NOT APPEAR ON THE DISPLAY WHEN ARCHIVING	32
6.8 NO DATA HAVE BEEN WRITTEN ON THE CARD	32
6.9 SDA GENERATES AN ERROR WHILE OPENING TREND FILES IN CHART DISPLAY.....	33
7. PROMPTS TRANSLATION	35

FIGURES

FIGURE 2-1	3
FIGURE 2-2	4
FIGURE 2-3	5
FIGURE 2-4	5
FIGURE 2-5	6
FIGURE 2-6	6
FIGURE 2-7	7
FIGURE 2-8	7
FIGURE 2-9	8
FIGURE 2-10	8
FIGURE 2-11	9
FIGURE 2-12	9
FIGURE 2-13	10
FIGURE 2-14	10
FIGURE 2-15	12

1. OVERVIEW

Before running your PCMCIA option, please read the following explanations on how to install it.

1.1 Warning

➤ If you received your optional PCMCIA board as a spare part:

You are going to install your optional PCMCIA board.

To run properly, this application needs recorder firmware release 001AK or higher.

To determine the version of your recorder firmware, refer to your product manual (sub-section 3-2) or read it on the recorder in SERVICE / MISCELLANEOUS, SOFTWARE.

If your recorder firmware release is lower than 001AK (or if you wish to upgrade it), follow the procedure given in the **PC Configurator Kit Notice (CK 214)**:

1. Install the PC configurator software (included in this kit) on your PC.

The minimum PC configuration required is a 486 with 4 Mb of RAM and 10 Mb free on your hard disk.

The software is compatible with Windows 3.1, Windows 3.11 and Windows 95.

2. Install the new recorder firmware (included in this kit) on your PC.
3. Connect the PC - Recorder interface (Kit # 46190409-501 **not included**).
4. Upgrade the recorder firmware.
5. Install the optional PCMCIA board as described in this manual (refer to Section 2; sub-section 2.1)
6. Configure the PCMCIA option board as described in section 3 of the manual.

➤ If you received your optional PCMCIA board with your recorder:

The PCMCIA board is already installed.

However, you have to configure the PCMCIA option as described in Section 3 of this manual.

➤ **Note that you can only upgrade the recorder firmware from the front panel of the recorder (with a jack cable) using the PC Configurator Kit.**

1.2 Main functions

- Selectable start conditions of archiving
- Rollover recording capability to keep the more recent informations
- Recorded informations selectable among: trends, alarms, digital events and internal diagnostics with configurable file names
- Recorded trends may be analog inputs, math results (if Maths option present) or communication PV's
- Ten selectable trends login frequencies from 1 second up to 30 minutes
- Check of the PCMCIA memory card (can be done before storing process data)
- PCMCIA event selectable on a configurable filling level
- Displaying PCMCIA card status (with specific led)
- Activating relay or displaying message on "PCMCIA" event
- PCMCIA memory cards used are ATA type II compatible and are made with the flash technology
- Internal buffer (128 Kb) to store the data during the change of the PCMCIA memory card.

2. INSTALLATION

2.1 Installing the PCMCIA option board

➔ **WARNING:** Please use an antistatic ground strap to avoid possible electrostatic damage to the printed circuit boards.

1. Turn off the power to isolate the recorder from the main supply.
2. Open the recorder door and remove the chart cassette from the chassis.
3. Turn OFF the switch. (See Figure 2-1)

Recorder's main power switch located behind the chart cassette




Figure 2-1

4. Remove the cover from the power supply terminal block. (See ref. E, Figure 2-15)
5. Disconnect the main supply from the power supply terminal block.
6. Unscrew the 3 fixing screws from the rear cover. (See ref. A, Figure 2-2)
7. Remove the rear cover. (See ref. B & C, Figure 2-2)




Figure 2-2

8. Remove all the terminal blocks. (See Figure 2-3)




Figure 2-3

9. Remove all the grommets. (See ref. A, Figure 2-4)

10. Unscrew the 4 fixing screws (M4) and remove from the chassis with the Torx key T20. (See ref. B, Figure 2-4)




Figure 2-4

11. Slide the recorder chassis out of the case. (See Figure 2-5).




Figure 2-5

12. Unscrew the 2 fixing screws from the power supply.
13. Remove the power supply by removing 5 screws; two at the top, one in the middle and two at the bottom. (See Figure 2-6)




Figure 2-6

14. Remove the slot covers in the right hand side location, and the Communications card if installed.
15. Remove the cover which protects the CPU board. Unscrew the 3 fixing screws. (See Figure 2-7).




Figure 2-7

16. Ensure your antistatic ground strap is connected to earth before proceeding to avoid possible electrostatic damage to the CPU board or PCMCIA board.
17. Disconnect the flat cable from the CPU board. (See Figure 2-8)




Figure 2-8

18. Remove the MMI flat cable plastic protection.
19. Remove the 3 flat cable clips. (See ref. A, Figure 2-9)
20. Remove the ink ribbon carriage stop (see ref. B standoff, Figure 2-9). Unscrew the fixing screw.
21. Remove the reinforcing bar (see ref. C, Figure 2-9) by unscrewing the 2 screws.




Figure 2-9

22. Unscrew the 3 fixing screws from the PCMCIA sub-assembly. (See Figure 2-10).




Figure 2-10

23. Remove the MMI with 2 screws (see B in Figure 2-11)
24. Put in place the PCMCIA sub-assembly on the left hand printer chassis side plate. (See Figure 2-11)
25. Fix the PCMCIA sub-assembly with the 3 screws M3. (See ref. A, Figure 2-11) one from the carriage stop.
WARNING: The 3 PCMCIA board fixing holes may have a wrong diameter (2.2 mm) but only on the very first 180 mm units.
In this case, you have to enlarge them to 3+ 0.5/0 mm.
 - Insert fully your memory card (not supplied) in the card guides.
 - Fix the memory card guides with the 2 screws M2. (See ref. B, Figure 2-11) by reinstalling the MMI.




Figure 2-11

26. Reinstall reinforcing bar (see ref. C, Figure 2-9)
27. Pass the PCMCIA flat cable through the opening at the rear of the printer chassis.
 - Fix the PCMCIA flat cable on the rear metal sheet with the double-side adhesive tape. (See ref. C, Figure 2-11). The adhesive tape is located on the flat cable.
 - Ensure the printer carriage can move properly.
28. Replace the MMI flat cable plastic protection.
29. Connect the PCMCIA flat cable to the CPU board (see Figure 2-12). Ensure the connectors are located correctly.




Figure 2-12

30. Put in place the MMI flat cable on the PCMCIA cover.
31. Fix it with the 2 flat cable clips supplied (with foam). (See ref. A, Figure 2-13)




Figure 2-13

32. Ensure the MMI can open properly.
 - Open the MMI fully.
 - Remove the protection of the double-side adhesive tape located on the PCMCIA cover.
 - Fix the MMI flat cable.
 - Put in place the MMI flat cable at the rear of the PCMCIA cover. (See ref. C, Figure 2-13)
33. Put in place the third MMI flat cable clip (not supplied) at the rear of the printer chassis. (See ref. B, Figure 2-13).
34. Connect the MMI flat cable to the CPU Board (see Figure 2-14). Ensure the connectors are located correctly.




Figure 2-14

35. Replace the CPU board protection cover.
Replace the 3 fixing screws.
36. Replace the slot covers.
37. Replace the power supply. Replace the 2 rightmost fixing screws.
38. Slide the recorder chassis back into the outer case.
39. Replace the 4 fixing screws (M4) with the Torx key T20. (See ref. B, Figure 2-4)
40. Replace all terminal blocks and grommets.
41. Replace the rear cover. Replace the 3 fixing screws. (See ref. A, Figure 2-2)
42. Reconnect the main supply to the power supply terminal block.
43. Replace the power supply terminal block cover. (See ref. E, Figure 2-15)
44. Turn ON the switch. (See Figure 2-1).
45. Replace the chart cassette.
46. Switch ON the main supply.
47. Upgrade your recorder firmware if the revision is lower than 001AK. (See CK 214).




Figure 2-15

3. OPERATION

3.1 Overview

3.1.1 PCMCIA card standard compatibility

The embeded PCMCIA driver supports all **ATA flash card devices** with a size from 2Mb up to 75Mb and is compatible with the PC card format (type II).

The write-protected signal available on these cards is not tested and not used because of a lack of standard rules.

3.1.2 PCMCIA card handling

If your recorder is equipped with the PCMCIA option board, you can use a memory card to store the recorder information.

For this, proceed as indicated in the following figure to introduce the memory card:




Figure 3-1: Card loading in the 180mm or 250mm recorder

Note: The recorder will automatically detect the card presence.

The recorder indicates the writing status by lighting a led located under the display (see Figure 3-2).

This led must be off when removing the memory card (this can be done with the remove or stop function), if not, some data may be lost.

To remove the memory card press the button located above it.




Figure 3-2: PCMCIA led in the 180mm or 250mm recorder

3.1.3 Archives summary

Archived data on a PCMCIA memory card may be:

- **charts** i.e analog inputs, math results or communication data,
- analog **alarms**,
- **digital** events,
- recorder **events**: (no paper, end of paper, burnout ...)

3.1.4 Recorder firmware compatibility

The PCMCIA option is compatible with the **001AK recorder firmware or higher**. Older firmware revisions will not allow your recorder to recognize the PCMCIA option board, the recorder will need to be updated (see the OVERVIEW section of this manual).

3.2 SETUP

3.2.1 PCMCIA communication interface configuration

The PCMCIA option board is detected at power up during the recorder's initialization time but, to be able to use it, the INTERFACE parameter of the MISCELLANEOUS configuration matrix must be set to PCMCIA.

The default configuration of this parameter is JACK, which allows to configure the recorder with the PC Configurator software.

When the option board has been detected, the PCMCIA configuration matrices (READ-WRITE, PRINT CONF and SERVICE) appear and this option becomes TRUE in recorder's hardware configuration (see the CARD USED service in the MISCELLANEOUS matrix).

SUB-MATRIX	PARAMETER	CLASSIFICATION
MISCEL	INTERFACE	◆◆♣♣
Definition:	Determines which of the PCMCIA option board or the JACK board is connected to the recorder.	
How to modify it:	Select a new value.	
Possible choices:	JACK PCMCIA	
Default value:	JACK	
Note:	This parameter cannot be modified by the PC Configurator software.	

Note: The PCMCIA service functions are only available when the interface parameter is set to PCMCIA.

3.2.2 PCMCIA card initialization

When using a memory card for the first time or when changing the file structure of that memory card (example: adding a file to it), it must be formatted by the recorder.

The recorder formats the memory card in a DOS compatible way and creates ALARMS, EVENTS and DIAGNOSTIC files if needed, the remaining space is used to create the TREND files.

To archive TRENDS on the memory cards, the DESTINATION parameter of the READ-WRITE\CHART matrix must be configured (see the chart configuration paragraph).

The storage frequency must also be programmed (see FREQUENCY parameter in the READ-WRITE\PCMCIA matrix).

The INITIALIZATION service is located in SERVICE\PCMCIA matrix. During its completion, "PCMCIA INIT" will be displayed and the PCMCIA led will light ON.

Note: All the created files are empty at the initialization time.

3.2.3 PCMCIA card test

The recorder has an internal function that enables to test the memory card. This test takes about 1 minute per Megabyte (4 minutes for a 4Mb memory card).

During the test the recorder checks the possibility to erase, write and read the entire memory space. Previous data are temporarily stored in a buffer and then re-written after the test so that this PCMCIA TEST function can be done on DOS formatted cards or not.

In case of error, the PCMCIA status is set to PCMCIA BAD, another status displayed means that the test has succeeded. (Refer to PCMCIA status § 4.2.2).

During the test the PCMCIA led lights on indicating that data are written on the card.

To stop this test at any time without damaging the card, press the SETUP key.

For more details see the TEST function in the PCMCIA\SERVICE matrix.

Note: Do not remove the card during the test function progress, this may damage the recorded data.

3.2.4 Charts selection

The TREND storage configuration is done in two steps:

- ☒ Select TRACE choice in the TRACE parameter of the READ-WRITE\CHART matrix.
- ☒ Select a value for the DESTINATION parameter, in the same matrix. See the following table:

<i>SUB-MATRIX</i>	<i>PARAMETER</i>	<i>CLASSIFICATION</i>
CHART	DESTINATION	♦ ♦ ♣ ♣
Definition:	Determines where to print or copy charts.	
How to modify it:	Select a new value.	
Possible choices:	ON PAPER: trends are printed on paper only ON FILE: trends are stored on PCMCIA only PAPER & FILE: trends are both printed and stored in TRENDS file	
Default value:	ON PAPER	
Note:	24 trends can be stored in the PCMCIA card TREND files with a 180 mm recorder. 32 trends can be stored in the PCMCIA card TREND files with a 250 mm recorder.	

3.3 Archive management

The archive management is detailed in the configuration chapter of this manual. Archiving on the PCMCIA memory card may be continuous or event driven depending on the START condition (see § 4.1.3).

3.3.1 Continuous archiving

If the START parameter is configured to CONTINUOUSLY, the information are continuously stored on the memory card.

However the archiving is stopped each time the measures are stopped, this may happen when a parameter of the configuration is changed or when a service function is running (all configuration or service parameters with the "♦♦" classification stop the measures and so the archiving when they are modified).

The archiving may also be stopped and restarted with the keyboard when the recording is continuous. On the contrary, the recording may be started and stopped again if the START parameter is set to NO ARCHIVE.

Note: At the beginning of the archiving, the alarms, the digital events and the recorder events which are active are recorded in the corresponding file with a star (*), this to indicate that the event or the alarm may be former to the recording date.

3.3.2 Event driven archiving

The recording may also be driven by a logic input or an alarm: an alarm on or a digital input closed to start the recording and the same alarm off or the same logic input opened to stop it (see § 4.1.3)

As in the continuous archiving mode, the operator can start or stop the archiving with the keyboard (see § 3.4).

The recorder continuously stores the alarms and events status changes in an internal buffer. Therefore, when the archiving starts, the recorder stores the latest alarm or event status change. Consequently the alarm or event dates may be prior to the archiving start date.

Note: When driving the archiving both with an event and with the keyboard, the latest action takes the priority.

3.4 Keyboard archive management

The archive may be managed automatically, but in addition some actions may be done with the keyboard.

3.4.1 START/STOP actions

By pressing the PRINT key it is possible to access to the "STOP ARCHIVE" or to the "START ARCHIVE" action depending whether the archiving is running or not.

When the storage is in progress, the "STOP ARCHIVE" message will be displayed, otherwise the "START ARCHIVE" message will be displayed.

The archiving can also be started or stopped by pressing F1 or F2 keys if the parameters F1 KEY or F2 KEY in the READ-WRITE\MMI matrix are configured to "START/STOP ARCH".

3.4.2 RESET PCMCIA files

The way to erase the files content (to start a new archive session) is to RESET the PCMCIA card by pressing RESET key and selecting the RESET PCMCIA choice. This is also an easy way to initialize a new PCMCIA card using.

WARNING → The RESET PCMCIA action will delete all the data stored on the card!
There is no backup done by the recorder. Information must be saved if needed with an external PC by using a File manager for example.

3.4.3 REMOVE PCMCIA function

To prevent any loss of data when removing the memory card, the REMOVE PCMCIA function must be used if the archiving is running (PCMCIA triangle lit ON).

The "REMOVE PCMCIA" action is accessible through the PRINT key.

The "REMOVE PCMCIA" action is also accessible by pressing the F1 or F2 keys if the parameters F1 KEY or F2 KEY in the READ-WRITE/MMI matrix are configured to "REMOVE PCMCIA".

The system data is saved so that the card can be removed.

During this time, PCMCIA card status becomes CARD PENDING and possible data will be stored in a temporary buffer.

3.5 PCMCIA information

3.5.1 PCMCIA status

The recorder provides a memory card status (see § 4.2.2 STATUS service) to help in the card utilization. This status may be one of the following cases:

Status	Description	Solution
PCMCIA MISSING *	There is no PCMCIA memory card inside the recorder or the card has not been detected.	Insert a compatible PCMCIA memory card
PCMCIA NOT INIT***	Card has been recognized but it has not been initialized.	Initialize the memory card (see § 4.2.2)
PCMCIA PENDING**	Data cannot be stored on the PCMCIA card because the configuration stored on it does not match the recorder configuration or there is no memory card.	Insert a memory card, Initialize it or reset it.(see § 4.2.2)
PCMCIA BAD***	Some data could not have been stored on PCMCIA because of a physical problem on it.	Change the memory card
CARD PRESENT*	A PCMCIA card is present with no problem detected.	
PCMCIA CONF CHG**	There is a difference between the configuration of the recorder and the parameters stored on the memory card, the parameters may be one of the following: the Id number, the language, the trace, the destination, the tagname and the engineering unit.	Restore the same configuration on the recorder or RESET the memory card.
PCMCIA FULL***	One of the PCMCIA files is nearly full according to the EVENT definition (see the "%FULL" parameter in § 4.1.3).	Remove the PCMCIA card and save the files on your computer. Introduce it back and reset it (see § 4.2.2).
PCMCIA DATA LOST**	This message is displayed if data to be written on the PCMCIA card have not been stored and have been removed from the internal buffer. This appears when the recorder archiving has started data and no memory card is inserted for a long period.	See the PENDING case


* Information accessible through the STATUS service described in the paragraph 4.1.3.

** Information displayed in run mode, not visible with the STATUS service.

*** Information displayed in run mode and visible with the STATUS service.

3.5.2 PCMCIA card status display

If PCMCIA card attribute is STORING, then a triangle appears. This means that any card removal could cause data losses on the card.



This triangle is turned off during the recorder configuration.

"PCMCIA BAD", "PCMCIA NOT INIT", "PCMCIA FULL" or "PCMCIA PENDING" could be displayed on the lower display as blinking message, depending on the corresponding status.

Note: The PCMCIA led must be lit on, for the recorder to be able to store data on the PCMCIA card.

3.5.3 PCMCIA event

The PCMCIA EVENT located in the READ-WRITE\EVENTS matrix (refer to the product manual) is activated if the PCMCIA card or the driver is in one of the following conditions:

MESSAGE DISPLAYED	DESCRIPTION	SOLUTION
PCMCIA NOT INIT	The card has not been initialized by the recorder.	Initialize the memory card.
PCMCIA BAD	There is a failure in the card device.	Change the memory card.
PCMCIA FULL	At least one archive file (TRENDS, ALARMS, EVENTS or DIAGNOSTIC) has reached the user-defined %full threshold (see the % FULL parameter in the READ-WRITE\PCMCIA matrix).	Save the files on your computer and reset the memory card (see § 4.2.2).

Note: When the PCMCIA FULL message is displayed, the recording continues till the 100% full is reached then all additional informations to this file are lost except if the ROLLOVER option is set (see § 4.1.3). Other files continue to be normally updated.

3.6 PCMCIA file descriptions

All PCMCIA card files are PC-compatible and are readable by the TrendManager Software package.

3.6.1 File name conventions

PCMCIA files have a fixed extension according to their content: TRENDS (*.LNT), ALARMS (*.LNA), EVENTS (*.LNE) and DIAGNOSTICS (*.LND).

The content of each type of file is:

- .LNT files contain CHARTS records
- .LNA files contain ALARMS records (all analog alarms)
- .LNE files contain DIGITAL events records
- .LND files contain recorder EVENTS records.


The recorder stores data depending on its configuration: TRENDS (**charts** channels records) informations are sent to the PCMCIA driver at user-defined frequency, ALARMS (**alarms** records), EVENTS (**digital events** records) and DIAGNOSTIC (**recorder events** records) are asynchronous informations and so, are sent at each occurrence.

3.6.2 Import data to the TrendManger software

The TrendManager Software Suite has a built in Data Conversion Tool that will accurately reproduce data from the Honeywell VRX recorder range

The data is imported from the device media using the TrendManager Pro Software Suite Import function into the database.


Select the Import button from the main tool bar and the External import box will appear.




Select the data option and select From Directory as the source location.

Use the Change button to browse your PC or network to locate the data.


Press the Import button when the correct location has been selected.



The User Acknowledgement box will appear; to proceed this must be acknowledged.



Select to import data to a New or Existing device. For an Existing device the Importing Controller box will display the existing devices in the TMP databases.



Select the device you wish to import the data from and click on Next. This will start the data importing.

If the data is for a New device, a list of device types will appear, select one and go to Next.



Enter a device name and description and click on OK.




Next choose the format type for the importing data. The two different formats are:


X Series (recommended) - This has the benefit of flexible pen scale limits that can be changed at any time in the X Series release of TrendServer. Data imported in this format cannot be loaded into a version 5 release of TrendServer.

Version 5 - Pen scale limits will be fixed once set, and any data values imported outside of the pen scale limits will be capped at the appropriate limit. However, this data can be read in by version 5 release of TrendServer. Click on OK and the data will start to import.

If there is a device in the database with the same Serial number but a different ID, this will be flagged up and you can choose to add the data to this device or a new device will be created. For a new device choose from the Database Device Destination User Selection box.



The Data File conversion will start and the destination box will appear to confirm the correct device. When the file conversion is complete press ok.



When the import is complete the data will be automatically displayed as a graph showing the data as pen traces and displaying each associated pen. Any events will be imported (via Trendbus only) with the data and can be displayed on the graph using the Event button at the bottom of the graph.

The device is loaded into the recorders list for identification purposes, click on the Recorders icon to display the list of recorders. The device can not be configured from the software. The imported data can be graphed, analyzed, archived, printed and exported to a spread sheet.

For data imported from Honeywell V5, X Series recorders, an Event viewer is available by right clicking on the recorder in the recorders list and selecting Events.

Refer to the TrendManager Pro Software Suite manual 43-TV-25-11 for further information.
Available at www.honeywell.com/ps

4. PCMCIA CONFIGURATION

4.1 PCMCIA sub-matrix parameters

4.1.1 PCMCIA sub-matrix parameters list



Position of
parameters



4.1.2 Explanation of the classification

This section will describe all the matrices that have been modified by the PCMCIA option and then, how configuration will be possible.

♦	Means that parameter can be modified in RUN mode (measures are still done)
♦ ♦	Means that parameter can be modified in STOP mode (measures are stopped)
♣	Means that parameter can be modified with password 1 or password 2
♣ ♣	Means that parameter can be modified with password 2 only

4.1.3 PCMCIA sub-matrix parameters description

SUB-MATRIX	PARAMETER	CLASSIFICATION
PCMCIA	START	♦ ♦ ♣ ♣
Definition:	Automatic start conditions	
How to modify it:	Select a new start condition	
Possible choices:	NO ARCHIVE CONTINUOUSLY DI CLOSED # AL ON #	
Default value:	NO ARCHIVE	
Note:	Stop conditions are the following: DI OPENED # AL OFF #	

<i>SUB-MATRIX</i>	<i>PARAMETER</i>	<i>CLASSIFICATION</i>
PCMCIA	ROLLOVER	♦ ♦ ♣ ♣
Definition:	Determines if, once the end of archive file has been reached, new data are copied at the beginning of this file, so that it contains the most recent data, or not.	
How to modify it:	Select or not rollover mode	
Possible choices:	DISABLE ENABLE	
Default value:	DISABLE	

<i>SUB-MATRIX</i>	<i>PARAMETER</i>	<i>CLASSIFICATION</i>
PCMCIA	LOG FREQ	♦ ♦ ♣ ♣
Definition:	Archive frequency used to log TRENDS files.	
How to modify it:	Select a new frequency.	
Possible choices:	1 s 5 s 10 s 15 s 30 s 1 mn 5 mn 10 mn 15 mn 30 mn	
Default value:	10 s	
Note:	In case of a change in the login frequency on the same file, the SDA software will make interpolations (depending if that option is configured or not) to produce a trend at the highest frequency. It is recommended in that case to read the file without interpolation.	

<i>SUB-MATRIX</i>	<i>PARAMETER</i>	<i>CLASSIFICATION</i>
PCMCIA	% FULL	♦ ♣
Definition:	Determines PCMCIA EVENT threshold.	
How to modify it:	Select a threshold in %.	
Possible choices:	0 to 100%	
Default value:	90% *	
See also:	PCMCIA in EVENTS matrix	

* The default value is 0% if the recorder was previously equipped with a firmware revision older than 001AK.

4.2 PCMCIA sub-matrix services

4.2.1 PCMCIA sub-matrix services list

SUB-MATRIX	➡	PCMCIA SERVICES
Position of parameters		
	➡	INITIALIZATION page 26
	➡	TEST page 26
	➡	SOFTWARE page 27
	➡	SIZE page 27
	➡	STATUS page 27
	➡	DIRECTORY page 28

NOTE: The memory card must be present in the recorder in order to access to the service functions and the INTERFACE parameter must be set to PCMCIA.

4.2.2 PCMCIA sub-matrix services description

SUB-MATRIX	PARAMETER	CLASSIFICATION
PCMCIA	INITIALIZATION	◆ ◆ ♣ ♣
Definition:	Formats and initializes PCMCIA board.	
How to use/execute it:	At first, you have to enter the number of records you want for ALARMS files: "Nb ALARM REC ?" is blinking and you can type it (1651 max). Then their file name (7 characters max.): "ALARM NAME ?" is blinking and you can type it . Then the number of records for EVENTS files: "Nb EVENT REC ?" is blinking and you can type it (1651 max). Then its file name (7 characters max.): "EVENT NAME ?" is blinking and you can type it. The number of records for DIAGNOSTIC files: "Nb DIAG REC ?" is blinking and you can type it (2667 max). Then its file name (7 characters max.): "DIAG NAME ?" is blinking and you can type it. And finally, we have to type TRENDS file names (7 characters max.) : "TREND NAME ?" is blinking and you can type it. During completion, "PCMCIA INIT" is displayed.	
Notes:	• At each step, you can abort this initialization by pressing SET UP key. • Default file names are "ALARM" for ALARM, "EVENT" for EVENT, and "DIAG" for DIAGNOSTIC and their extensions are automatically added. If another file name has been entered, then it takes the place of the default one for the following answers. • A digital index is automatically added to trend file names on PCMCIA card. • ALARM, EVENT and DIAG records are organized in blocks and the files use sectors of 512 bytes (as in the DOS) so that the effective number of records may be greater than the programmed number of records. • If the number of records is set to "0", the corresponding file is not created.	

SUB-MATRIX	PARAMETER	CLASSIFICATION
PCMCIA	TEST	◆ ◆ ♣ ♣
Definition:	Tests PCMCIA device.	
How to use/execute it:	By pressing ENTER, PCMCIA board driver tests the whole PCMCIA device: during execution, the percentage of test completion is displayed on the screen: For example: "15% PASSED" If an error occurs during this test, "FAILED" appears during 2s. Test is aborted and PCMCIA status becomes PCMCIA BAD.	
Note:	At any moment, you can abort the process by using SETUP key. The test duration is about 1 minute per Megabyte of capacity.	

SUB-MATRIX	PARAMETER	CLASSIFICATION
PCMCIA	SOFTWARE	♦ ♣
Definition:	PCMCIA board driver software revision.	
How to use/execute it:	You can only read the value.	
	You can exit by pressing SETUP key.	

SUB-MATRIX	PARAMETER	CLASSIFICATION
PCMCIA	SIZE	♦ ♣
Definition:	PCMCIA board size in Mb.	
How to use/execute it:	You can only read the value.	
	You can exit by pressing SETUP key.	

SUB-MATRIX	PARAMETER	CLASSIFICATION
PCMCIA	STATUS	♦ ♣
Definition:	Return status of PCMCIA board.	
	PCMCIA board status could be:	
	PCMCIA MISSING: the card is not inboard	
	PCMCIA NOT INIT: the card has to be initialized (cf INITIALIZATION parameter in this matrix)	
	PCMCIA BAD: the card cannot be correctly used by the PCMCIA driver. Initialize it again or test it.	
	PCMCIA FULL: at least, one of the included file is full according to the threshold configured by the user (cf "%FULL" parameter in READ/WRITE PCMCIA matrix.	
How to use/execute it:	PCMCIA PRESENT: the card is ready to be used	
	You can only read the status.	
	You can exit by using SETUP key.	

PCMCIA	DIRECTORY	◆ ♣
Definition: How to use/execute it:	Allows you to read PCMCIA card directory: the names of the files on the memory card (with DOS extension), the number of records used and remaining per file are displayed (only the files compatible with the recorder data are displayed). If a file exists, its name and its index are first displayed in the PCMCIA card: <u>Ex</u> : 01 ALARM.LNA With the ↑ and ↓ keys, you can scroll all SDA files written on the card. The ← and → keys allow you to display the number of records already used in this file and the number of remaining records. The file index is still displayed to show you which is the corresponding file. <u>Ex</u> : Press →. Then the following message appears on the display: 01 U: 12 That means that 12 records have already been written on the 1st file. Press → again: The following string is shown: 01 R: 1488 That means that 1488 records are still available for this 1st file. Or the following string is shown for TREND files: 01 R : 1 10 : 45 That means that there is still space for 1 day 10 hours and 45 minutes of archiving time. Note that except for TREND files, the total number of records corresponds to the size given or computed during PCMCIA card initialization. You can exit by using SETUP key.	

5. KITS LIST

KITS LIST	PART #
PCMCIA upgrade kit	46190163-501
Compact Flash Card 256MB	50001011-504
Compact Flash to PCMCIA Adapter	50001014-501
TrendManager Analysis software	50016133-501

6. TROUBLESHOOTING

6.1 PCMCIA option is not recognized by the recorder (PCMCIA matrix does not appear)

CHECK

Check if the flat cable connection between PCMCIA board and CPU board is correct.

DIAGNOSTIC / ACTION

1. **NO:** Check for the proper connection.

6.2 PCMCIA INIT service is not possible

CHECK

Is PCMCIA memory card really plugged into the driver?

Is problem corrected ?

DIAGNOSTIC / ACTION

1. **NO:** Insert the card into the board.

2. **NO:** Verify you only use **ATA flash card** devices (see Section 5 - Kits list for certified cards).

6.3 "PCMCIA FULL" message is displayed on the recorder

CHECK

What is the threshold value in READ-WRITE\PCMCIA matrix?

Is problem corrected ?

DIAGNOSTIC / ACTION

1. Increase this value to disable "PCMCIA FULL" message display.

2. **NO:** Initialize PCMCIA card again with INIT utility in PCMCIA / SERVICE matrix and increase the number of records for the files which are too small.

6.4 "PCMCIA NOT INIT" message is displayed on the recorder

CHECK

DIAGNOSTIC / ACTION

1. Initialize the card by using INIT menu in PCMCIA / SERVICE matrix.

6.5 "PCMCIA BAD" message is displayed on the recorder

CHECK

Is the card readable by an external driver?

DIAGNOSTIC / ACTION

1. **NO:** Change the card.

2. **YES:** Run a TEST (PCMCIA / SERVICE).
- If the test is successful, then the card is OK.
- If the test stops before reaching 100 % of completion then an area of the card is bad. The card has to be changed.

6.6 “PCMCIA PENDING” message is displayed on the recorder

CHECK	DIAGNOSTIC / ACTION
Check the PCMCIA STATUS in PCMCIA / SERVICE :	
PCMCIA MISSING	The archive is ON and no card has been inserted in the driver. Insert a card to turn off the display.
PCMCIA BAD	The archive is ON and the inserted card is bad. Refer to § 6.5 to check card validity or insert a valid card.
PCMCIA NOT INIT	The archive is ON and the inserted card is not initialized. Refer to § 6.4.
PCMCIA PRESENT	The card has been initialized but part of the archiving configuration stored on the card does not match with the configuration of the recorder. Press RESET key and select RESET PCMCIA menu to make both configurations match.
WARNING → A RESET PCMCIA will erase all previous data stored on the card.	

6.7 PCMCIA triangle does not appear on the display when archiving

CHECK	DIAGNOSTIC / ACTION
Check INTERFACE parameter in MISCELLANEOUS / Read/Write	Turn parameter to PCMCIA.
Check START parameter in PCMCIA / Read/Write	If the archive is triggered by an alarm or a digital status, check alarm or digital status which should start the archiving (Press the DISPLAY key and select ALARM STATUS or LOGIC STATES).
Is PCMCIA PENDING displayed on the MMI ?	Refer to § 6.6

6.8 No data have been written on the card

CHECK	DIAGNOSTIC / ACTION
Check START parameter in PCMCIA / Read/Write	The archiving start condition has not been met. No data have been stored on the card.
Was PCMCIA PENDING displayed on the MMI ?	Refer to § 6.6
Check ROLLOVER parameter in PCMCIA / Read/Write	If ROLLOVER is set on DISABLE, check in DIRECTORY (PCMCIA / SERVICE) the amount of records that it is still possible to store. If this amount is 0, no data will be recorded on this file. Turn ROLLOVER to ENABLE or either reset or initialize the card.

6.9 SDA generates an error while opening trend files in chart display

CHECK

DIAGNOSTIC / ACTION

1. An archived Math function has returned an error code which prevents SDA from charting correctly this channel. Open the trend file in the data table format and note the math in error. Open the trend file in the trend format and remove the math function in error from the list of selected traces to be charted.

2. When the archiving process is incorrectly interrupted (ie : power off while archiving), it may happen that SDA displays an error message while opening the archive files. Files are nevertheless still readable except for their last data part. It is then recommended in that case to reduce the last time to display in the SDA opening trend files window.

7. PROMPTS TRANSLATION

EN	FR	GE	SP	IT
----	----	----	----	----

PCMCIA
CONFIRM

PCMCIA
CONFIRMER

PCMCIA
BESTÄTIGEN

PCMCIA
CONFIRM

PCMCIA
CONFERMA

PARAMETERS

START	DEMARRAGE	START	EMPEZAR	PARTENZA
ROLLOVER	RE-ENRG	UEBERSCHR	VUELTA	RICARICARE
LOG FREQ	FREQ ENRG	FREQ AUFZ	FREC LOG	FREQ LOG
% FULL	% PLEIN	% VOLL	% LLENO	% PIENO
INIT	INIT	INIT	INICIALIZ	INIZIALIZZA
TEST	TEST	TEST	PRUEBA	TEST
SOFTWARE	LOGICIEL	SOFTWARE	SOFTWARE	SOFTWARE
SIZE	TAILLE	GROESSE	TAMANO	DIMENSIONE
STATUS	ETAT	STATUS	ESTADO	STATO
DIRECTORY	REPertoire	VERZEICHNIS	REPertorio	DIRECTORY

POSSIBLE VALUES

NO ARCHIVE	PAS ARCHIVE	KEIN ARCHIV	NO ARCHIVO	NO ARCHIVIO
AL ON #	AL ON N°	AL EIN NR	AL ACTIV #	ALL ON#
DI CLOSED#	LO FER N°	BI SCHL NR	ED CERRA #	DI CHIUSO#
CONTINUOUSLY	CONTINU	DAUERND	CONTINUAMENT	CONTINUO
NB ALARM REC?	NB PTS ALARME ?	ANZ REG ALARM	N REG ALARMAS ?	N PUNTI ALLARME
ENABLE	AUTORISE	AKTIVIEREN	ACTIVAR	ABILITATO
DISABLE	REFUSE	INAKTIVIEREN	DEACTIVAR	DISABILITATO
ALARM NAME?	NOM ALARME ?	ALARM BEZEICHNG	NOMBRE ALARMA ?	NOME ALLARMI
NB EVENT REC?	NB PTS EVT ?	ANZ REG EREIGN	N REG EVENTOS ?	N PUNTI EVENTI
EVENT NAME	NOM EVT ?	EREIGN BEZEICHNG	NOMBRE EVENTO ?	NOME EVENTI
NB DIAG REC?	NB PTS DIAG ?	ANZ REG DIAGR	N REG DIAG ?	N PUNTI DIAG
DIAG NAME	NOM DIAG ?	DIAGR BEZEICHNG	NOMBRE DIAG ?	NOME DIAG
TREND NAME	NOM TRACE ?	TREND BEZEICHNG	NOMBRE TRAZA ?	NOME TRACCE
% PASSED	% TEST BON	% ERFOLG	% BUENA	% TEST BUONO
FAILED	ECHEC	FEHLERHAFT	MALA	NO RIUSCITO
PCMCIA BAD	PCMCIA MAUVAISE	PCMCIA AUSFALL	PCMCIA DEFEC	PCMCIA GUASTA
PCMCIA FULL	PCMCIA PLEINE	PCMCIA VOLL	PCMCIA LLENA	PCMCIA PIENA
PCMCIA NOT INIT	PCMCIA NON INIT	PCMCIA NICHT INI	PCMCIA SIN INIC	PCMCIA NON INIZ
PCMCIA PENDING	PCMCIA EN ATT.	PCMCIA WARTEZUST	PCMCIA PENDIENTE	PCMCIA IN ATTESA
PCMCIA DATA LOST	PERTE DE DONNEES	VERLOR DATEN	DATOS PERDIDOS	DATI PERSI
PCMCIA PRESENT	PCMCIA PRESENTE	PCMCIA VORHANDEN	PCMCIA PRESENTE	PCMCIA PRESENTE
PCMCIA MISSING	PCMCIA ABSENTE	PCMCIA VERREIST	PCMCIA SACADA	PCMCIA ASSENTE
REMOVE PCMCIA	RETIRER PCMCIA	ENTFERNE PCMCIA	QUITAR PCMCIA	TOGLIERE PCMCIA
RESET PCMCIA	RAZ PCMCIA	PCMCIA ZURUECKS	REINICIAR PCMCIA	RESET PCMCIA
PCMCIA INIT	INIT PCMCIA	INIT PCMCIA	INIC PCMCIA	INIZIALIZ PCMCIA
Mb	Mo	MB	Mb	MB
PCMCIA CONF	PCMCIA CHGT CONF	PCMCIA KONFÄNDRG	CAMB CONF	CAMB CONF
CHG			PCMCIA	PCMCIA
START ARCHIVE	DEBUT ARCHIVE	START ARCHIVIERG	INICIAR ARCHIVO	START ARCHIVIO
STOP ARCHIVE	FIN ARCHIVE	STOP ARCHIVIERG	PARAR ARCHIVO	STOP ARCHIVIO
PCMCIA EVENT	EVT PCMCIA	PCMCIA EREIG	SUC PCMCIA	EVEN PCMCIA
WAIT PLEASE	ATTENDEZ SVP	BITTE WARTEN	ESPERE P. FAVOR	ATTENDERE
INTERFACE	INTERFACE	INTERFACE	INTERFASE	INTERFACCIA
s	s	SEKUNDE	s	s
		SEKUNDEN		
mn	mn	MINUTE	mn	mn
		MINUTEN		

Sales and Service

For application assistance, current specifications, pricing, or name of the nearest Authorized Distributor, contact one of the offices below.

ARGENTINA

Honeywell S.A.I.C.
Belgrano 1156
Buenos Aires
Argentina
Tel. : 54 1 383 9290

ASIA PACIFIC

Honeywell Asia
Pacific Inc.
Room 3213-3225
Sun Kung Kai Centre
N° 30 Harbour Road
Wanchai
Hong Kong
Tel. : 852 829 82 98

AUSTRALIA

Honeywell Limited
5 Thomas Holt Drive
North Ryde Sydney
Nsw Australia 2113
Tel. : 61 2 353 7000

AUSTRIA

Honeywell Austria
G.M.B.H.
Handelskai 388
A1020 Vienna
Austria
Tel. : 43 1 727 800

BELGIUM

Honeywell S.A.
3 Avenue De Bourget
B-1140 Brussels
Belgium
Tel. : 32 2 728 27 11

BRAZIL

HONEYWELL DO
Brazil
And Cia
Rua Jose Alves Da
Chunha
Lima 172
Butanta
05360.050 Sao Paulo
Sp
Brazil
Tel. : 55 11 819 3755

BULGARIA

HONEYWELL EOOD
14, Iskarsko Chausse
POB 79
BG- 1592 Sofia
BULGARIA
Tel : 359-791512/
794027/ 792198

CANADA

Honeywell Limited
The Honeywell Centre
300 Yorkland Blvd.
Toronto, Ontario
M2j 1s1
Canada
Tel.: 800 461 0013
Fax:: 416 502 5001

CZECH REPUBLIC

HONEYWELL,
Spol.S.R.O.
Budejovicka 1
140 21 Prague 4
Czech Republic
Tel. : 42 2 6112 3434

DENMARK

HONEYWELL A/S
Automatikvej 1
DK 2860 Soeborg
DENMARK
Tel. : 45 39 55 56 58

FINLAND

HONEYWELL OY
Ruukintie 8
FIN-02320 ESPOO 32
FINLAND
Tel. : 358 0 3480101

FRANCE

HONEYWELL S.A.
Bâtiment « le Mercury »
Parc Technologique de St
Aubin
Route de l'Orme
(CD 128)
91190 SAINT-AUBIN
FRANCE
Tel. from France:
01 60 19 80 00
From other countries:
33 1 60 19 80 00

GERMANY

HONEYWELL AG
Kaiserleistrasse 39
D-63067 OFFENBACH
GERMANY
Tel. : 49 69 80 64444

HUNGARY

HONEYWELL Kft
Gogol u 13
H-1133 BUDAPEST
HUNGARY
Tel. : 36 1 451 43 00

ICELAND

HONEYWELL
Hataekni .hf
Armuli 26
PO Box 8336
128 reykjavik
Iceland
Tel : 354 588 5000

ITALY

HONEYWELL S.p.A.
Via P. Gobetti, 2/b
20063 Cernusco Sul
Naviglio
ITALY
Tel. : 39 02 92146 1

MEXICO

HONEYWELL S.A. DE
CV
AV. CONSTITUYENTES
900
COL. LOMAS ALTAS
11950 MEXICO CITY
MEXICO
Tel : 52 5 259 1966

THE NETHERLANDS

HONEYWELL BV
Laaderhoogtweg 18
1101 EA AMSTERDAM
ZO
THE NETHERLANDS
Tel : 31 20 56 56 911

NORWAY

HONEYWELL A/S
Askerveien 61
PO Box 263
N-1371 ASKER
NORWAY
Tel. : 47 66 76 20 00

POLAND

HONEYWELL Sp.z.o.o
Ul Domaniewska 41
02-672 WARSAW
POLAND
Tel. : 48 22 606 09 00

PORTUGAL

HONEYWELL
PORTUGAL LDA
Edificio Suecia II
Av. do Forte nr 3 - Piso 3
2795 CARNAXIDE
PORTUGAL
Tel. : 351 1 424 50 00

REPUBLIC OF IRELAND

HONEYWELL
Unit 1
Robinhood Business
Park
Robinhood Road
DUBLIN 22
Republic of Ireland
Tel. : 353 1 4565944

REPUBLIC OF SINGAPORE

HONEYWELL PTE LTD
BLOCK 750E CHAI
CHEE ROAD
06-01 CHAI CHEE IND.PARK
1646 SINGAPORE
REP. OF SINGAPORE
Tel. : 65 2490 100

REPUBLIC OF SOUTH AFRICA

HONEYWELL
Southern Africa
PO BOX 138
Milnerton 7435
REPUBLIC OF SOUTH
AFRICA
Tel. : 27 11 805 12 01

ROMANIA

HONEYWELL Office
Bucharest
147 Aurel Vlaicu Str.,
Sc.Z.,
Apt 61/62
R-72921 Bucharest
ROMANIA
Tel : 40-1 211 00 76/
211 79

RUSSIA

HONEYWELL INC
4 th Floor Administrative
Building of AO "Luzhniki"
Management
24 Luzhniki
119048 Moscow
RUSSIA
Tel : 7 095 796 98 00/01

SLOVAKIA

HONEYWELL Ltd
Mlynske nivy 73
PO Box 75
820 07 BRATISLAVA 27
SLOVAKIA
Tel. : 421 7 52 47 400/425

SPAIN

HONEYWELL S.A
Factory
Josefa Valcarcel, 24
28027 MADRID
SPAIN
Tel. : 34 91 31 3 61 00

SWEDEN

HONEYWELL A.B.
S-127 86 Skarholmen
STOCKHOLM
SWEDEN
Tel. : 46 8 775 55 00

SWITZERLAND

HONEYWELL A.G.
Hertistrasse 2
8304 WALLISELLEN
SWITZERLAND
Tel. : 41 1 831 02 71

TURKEY

HONEYWELL A.S.
Caryiyolu Sok No. 7
Ucgen Plaza, Kat 5-6-7
Icerenkoy 81120
Istanbul
Turkey
Tel (90-216) 575 66 00

UNITED KINGDOM

HONEYWELL
Honeywell House
Arlington Business Park
Bracknell,
Berkshire
RG12 1EB
Tel: +44 (0) 1344 656000

U.S.A.

HONEYWELL
PROCESS SOLUTIONS
512 Virginia Drive
Ft. Washington Pa 19034
U.S.A.
Tel. : +1 215-641-4300

VENEZUELA

HONEYWELL CA
APARTADO 61314
1060 CARACAS
VENEZUELA
Tel. : 58 2 239 0211

Honeywell Field Solutions

2500 W. Union Hills Dr.

Phoenix, AZ 85027

Tel: 877.466.3993 or 602.313.6665

www.honeywell.com/ps

EN1I-6208

May 2008

© 2008 Honeywell International Inc.

