

# Installation & Maintenance Instructions

2 – POSITION 4–WAY SOLENOID VALVES  
BRASS CONSTRUCTION  
1/4" NPT – AIR OR INERT GAS SERVICE

SERIES

8345

Form No.V6865R1

**IMPORTANT:** See separate solenoid installation and maintenance instructions for information on: Wiring, Solenoid Temperature, Causes of Improper Operation, Coil, or Solenoid Replacement.

## DESCRIPTION

Series 8345 valves are 2– position 4–way solenoid valves designed for air or inert gas service. Valve bodies are made of rugged brass. The valves may be provided with a low power or intrinsically safe solenoid.


## OPERATION

**Solenoid De–energized:** Flow is from Pressure P to Cylinder A and from Cylinder B to Exhaust EB. Exhaust EA is closed.

**Solenoid Energized:** Flow is from Pressure P to Cylinder B and from Cylinder A to Exhaust EA. Exhaust EB is closed.

**IMPORTANT:** Minimum operating pressure differential is 10 psi.

## Flow Diagrams



## INSTALLATION

Check nameplate for correct catalog number, pressure, voltage, frequency, and service. Never apply incompatible fluids or exceed pressure rating of the valve. Installation and valve maintenance to be performed by qualified personnel.

## Temperature Limitations

Fluid and ambient temperature range:  $-4^{\circ}\text{F}$  to  $+140^{\circ}\text{F}$ .

## Future Service Considerations

Provision should be made for performing seat leakage, external leakage, and operational tests on the valve with a nonhazardous, noncombustible fluid after disassembly and reassembly.

## Positioning

Valve may be mounted in any position.

## Mounting

For mounting valve body refer to Figure 1.




Figure 1. Dimensions for mounting valve body.

## Piping

There are two exhaust ports EA and EB. Exhaust ports EA and EB may be connected to a common exhaust if the air or inert gas cannot be exhausted directly to the atmosphere. Connect piping or tubing to valve according to markings on valve body. Refer to flow diagrams in *OPERATION* section.

**▲ CAUTION:** To avoid damage or accidental disengagement of cartridge assembly from valve body, hold cartridge assembly securely by wrenching flats when installing or removing piping at Port EB.

Apply pipe compound sparingly to male pipe threads only. If applied to valve threads, the compound may enter the valve and cause operational difficulty. Avoid pipe strain by properly supporting and aligning piping. When tightening the pipe, do not use valve or solenoid as a lever. Locate wrenches applied to valve body or piping as close as possible to connection point.


To insure proper operation of the valve, the pressure and exhaust lines must be full area without restriction. A minimum differential pressure (10 psi), as stamped on the nameplate, must be maintained between pressure and exhaust at the moment of shifting. Air reservoirs must have adequate capacity to maintain this minimum pressure during shifting. To check pressure during shifting, install a pressure gauge in the pressure piping as close to the valve as possible.




**IMPORTANT:** These solenoid valves are intended for use on clean dry air or inert gas, filtered to 50 micrometres or better. The dew point of the media should be at least 10°C (18°F) below the minimum temperature to which any portion of the clean air/inert gas system could be exposed to prevent freezing. If lubricated air is used, the lubricants must be compatible with Buna N elastomers. Diester oils may cause operational problems. Instrument air in compliance with ANSI/ISA Standard S7.3–1975 (R1981) exceeds the above requirements and is, therefore, an acceptable media for these valves.

#### Flow Controls (Speed or Metering Devices)

Flow control valves may be added to control cylinder speed. If used, these flow control valves must be located in cylinder piping between the solenoid valve and the cylinder.

**IMPORTANT:** Do not install flow controls (speed or metering devices) or any type of restrictive device in either the Pressure P (inlet) or the Main Exhaust EA or Pilot Exhaust EB (outlet) ports of the valve. Restricting any of these lines may cause valve malfunction.



-  — Indicates location of pressure gauge
-  — Indicates location of filter
-  — Indicates location of metering device

**IMPORTANT**  
A minimum operating pressure differential of 10 PSI must be maintained during shifting.

Figure 2. Series 8345 piping diagram.

### MAINTENANCE

**▲ WARNING:** To prevent the possibility of personal injury or property damage, turn off electrical power, depressurize valve, and vent fluid to a safe area before servicing the valve.

**NOTE:** It is not necessary to remove the valve body from the pipeline for repairs. However, piping or tubing must be removed from Pressure P and Exhaust EB ports.

#### Cleaning

All solenoid valves should be cleaned periodically. The time between cleanings will vary depending on the medium and service conditions. In general, if the voltage to the coil is correct, sluggish valve operation, excessive noise or leakage will indicate that cleaning is required. In the extreme case, faulty valve operation will occur and the valve may fail to shift. Clean filter when cleaning the valve.

## Preventive Maintenance

- Keep the medium flowing through the valve as free from dirt and foreign material as possible.
- While in service, the valve should be operated at least once a month to insure proper opening and closing.
- Depending on the medium and service condition, periodic inspection of internal valve parts for damage or excessive wear is recommended. Thoroughly clean all parts. If parts are worn or damaged, install a complete ASCO Rebuild Kit.

## Causes of Improper Operation

- **Incorrect Pressure:** Check valve pressure. Pressure to valve must be within range specified on nameplate.
- **Excessive Leakage:** Disassemble valve and install a complete ASCO Rebuild Kit.

## Valve Disassembly

1. Disassemble valve in an orderly fashion using exploded view for identification and placement of parts. Refer to Figure 3 on page 4 of 4.
2. Remove piping from Pressure P and Exhaust EB ports.
3. Remove solenoid, see separate instructions.
4. Unscrew cartridge assembly from valve body. Then remove cartridge gasket from valve body and orifice gasket from base of cartridge assembly.
5. Unscrew end cap and remove end cap gasket, body gasket, and disc from valve body cavity.
6. Unscrew end plug and remove end plug gasket and piston with piston u-cup from valve body cavity.
7. Clean valve and install a complete ASCO Rebuild Kit.

## Valve Reassembly

1. Lubricate piston u-cup and all gaskets with DOW CORNING® 111 Compound lubricant or an equivalent high-grade silicone grease.
2. Position piston u-cup on piston with mouth or open end facing outward, in the direction of the end plug.

3. Install end plug gasket on end plug.
4. Install piston with u-cup, end plug gasket, and end plug into the valve body. Torque end plug to  $200 \pm 10$  in-lbs [ $22,6 \pm 1,1$  Nm].
5. Install end cap gasket on end cap. Then position body gasket and disc in valve body cavity and install the end cap with the end cap gasket. Torque end cap to  $200 \pm 10$  in-lbs [ $22,6 \pm 1,1$  Nm].
6. Position cartridge gasket in valve body.
7. Install orifice gasket in recess in base of cartridge assembly.
8. Thread cartridge assembly with orifice gasket into valve body. Torque cartridge assembly to  $175 \pm 25$  in-lbs [ $19,8 \pm 2,8$  Nm].
9. Install solenoid see separate instructions.
10. Make up piping to pressure P and pilot exhaust EB ports and electrical connection to solenoid.

**▲ WARNING:** To prevent the possibility of personal injury or property damage, check valve for proper operation before returning to service. Also perform internal seat and external leakage tests with a nonhazardous, noncombustible fluid.

11. Restore line pressure and electrical power supply to valve.
12. After maintenance is completed, operate the valve a few times to be sure of proper operation.

## ORDERING INFORMATION

### FOR ASCO REBUILD KITS

Parts marked with an asterisk (\*) in the exploded view are supplied in Rebuild Kits. When Ordering Rebuild Kits for ASCO valves, order the Rebuild Kit number stamped on the valve nameplate. If the number of the kit is not visible, order by indicating the number of kits required, and the Catalog Number and Serial Number of the valve(s) for which they are intended.

### Torque Chart

Part Name	Torque Value In—lbs	Torque Value Nm
Cartridge Assembly	175 ± 25	19,8 ± 2,8
End Plug	200 ± 10	22,6 ± 1,1
End Cap		




Figure 3. Series 8345 without solenoid.