

## DCP300

## Digital Controller Programmer

## Model Selection Guide

### Instructions

- Select the desired Key Number. The arrow to the right marks the selection available.
- Make one selection each from Table I thru VI, using the column below proper arrow.
- A dot (•) denotes unrestricted availability. A letter denotes restricted availability.

Key Number	I	II	III	IV	V	VI
-----	-	-	-	-	-	-

KEY NUMBER	Description	Selection	Availability
1 Channel Digital Controller/Programmer	P301	↓	
2 Channel Digital Controller/Programmer	P302	↓	↓

**TABLE I**

Outputs	Channel 1	Channel 2 (P302 Only)	0D			
				•	•	
Relay (5 Amp)	Current	0D	•	•		
Position Proportional	Current	2G	•	•		
Current (4 - 20 mA)	Current	5G	•	•		
Relay/Relay (Heat/Cool)	Current	3D	•	•		
Current/Current (Heat/Cool)	Current	5K	•	•		

**TABLE II**

Inputs	One Input Channel	0	•	
	Two Input Channels	1		•
	Temperature/Relative Humidity Calculation	2		•

**TABLE III**

Power	Universal Power - 90 to 264 VAC, 50/60 Hz	ES	•	•
-------	---	----	---	---

**TABLE IV**

Option 1	None	00	•	•
	1 Auxiliary Output	01	•	a
	2 Auxiliary Outputs	02	a	

**TABLE V**

Option 2	4 Digital Inputs + 3 Events - (Standard features)	0	•	•
	12 Digital Inputs + 3 Events + 5 Time Events	1	•	•

**TABLE VI**

None	00	•	•
------	----	---	---

**RESTRICTIONS**

Restriction Letter	Not Available With		Available Only With	
	Table	Selection	Table	Selection
a	I	2G, 3D, 5K	I	0D, 5G